



Composition: Emergency Indicator Release  
SKU: 789-EF


Emergency Indicator Release, a safety device typically used in privacy or WC door locks which shows if room is occupied. it allows to unlock the door from outside in an emergency.




TOP




SIDE




FRONT



FRONT



SIDE



BACK